



Version 10.28.25

**USER MANUAL**

**TURBOTUNE**

**HAVE QUESTIONS OR  
NEED ADDITIONAL SUPPORT?**

---

**support@mdttac.com  
+1 (604) 393-0800**

**WANT TO LEARN MORE?  
CHECK OUT OUR INSTALL VIDEO**



1. To adjust, insert Turbotune into one of the slots of the tool and use the body of the tool for leverage.

Note: The top slot is great for opening and closing the feed lips. The side slot is better for opening or closing the splay of the feedlips.

2. Check your feed lip spacing by inserting the tip of the tool vertically into the feed lips so the text is facing the front and back of the mag (one side is imperial, the other metric). Make sure the measurement lines up with the recommended values on the tool for your cartridge.

\*This is not a precision measurement tool, it is only intended to give you an approximate width dimension when in the field\*